

- 1. Place 4x4 wood post in 12" x 3' deep hole; backfill shall be compacted around post.
- 2. All bolts shall be 1/4" galvanized with washers.
- 3. Attach the Kansas City Works sign to sign supports with 1" galvanized wood screws and washers at 2' 0" centers around the perimeter.
- 4. Three Sizes: Type $A 2^{\circ}x3^{\circ}$ Type $B 4^{\circ}x6^{\circ}$ Type $C 16^{\circ}x8^{\circ}$
- 5. Nominal sizes of posts and braces are shown. Actual sizes are to be the Industry Standard, 1 ½" x 3 ½" (2x4), and 3 ½" x 3 ½" (4x4)